## CROSS CONNECTON CONTROL AND BACKFLOW PREVENTION

Starting and Maintaining a Program for your Water System

#### **BACKFLOW PREVENTION TYPES**



Gary Rager Utah Division of Drinking Water 801-536-4498 grager@utah.gov



### **BACKFLOW PREVENTION**

METHODS TO PROTECT CROSS CONNECTIONS AND PREVENT BACKFLOW

#### **BACKFLOW PREVENTION TYPES**

BACKFLOW PREVENTION ASSEMBLIES

BACKFLOW PREVENTION DEVICES

AIR GAPS

### **BACKFLOW ASSEMBLIES**

### **BACKFLOW ASSEMBLIES**

- In line testable
  - Tested annually by a certified Backflow Assembly Tester
- In line repairable
- Isolation valves and test ports

### BACKFLOW ASSEMBLY TYPES

Reduced Pressure Zone Backflow Assembly

Double Check Valve Backflow Assembly


Pressure Vacuum Breaker Backflow Assembly

Spill Proof Vacuum Breaker Backflow Assembly

### REDUCED PRESSURE ZONE (RPZ) BACKFLOW ASSEMBLY


MAINTAINING AS AN ASSEMBLY

**ISOLATION VALVES (2)** 



TEST PORTS
(4)

**RELEIF PORT (1)** 




### REDUCED PRESSURE ZONE BACKFLOW ASSEMBLY

- Approved For:
  - Approved for Backpressure and Backsiphonage
  - Health and Non Health hazards
- Common Applications
  - Landscape irrigation systems
  - Boilers
  - Chemicals

### REDUCED PRESSURE ZONE (RPZ) BACKFLOW ASSEMBLY

- Installation Criteria
  - Installed horizontally only (unless 3<sup>rd</sup> party approved for vertical installation)
  - 12 inch clearance between relief port and grade line
  - May NOT be installed in a pit or a vault
  - Shall not be directly connected to a drain line

### BACKFLOW ASSEMBLY






### BACKFLOW ASSEMBLY

MAINTAINING AS AN ASSEMBLY

**ISOLATION VALVES (2)** 



TEST PORTS (4)





## DOUBLE CHECK VALVE BACKFLOW ASSEMBLY

- Approved For:
  - Approved for Backpressure and Backsiphonage
  - Non Health hazard only
- Common Applications
  - Food service applications
  - Dairy
  - Bottling plants
  - Multi-story buildings
  - Fire suppression systems without hazardous chemical additives (class 1 & 2)

## DOUBLE CHECK VALVE BACKFLOW ASSEMBLY

- Installation Criteria
  - Installed horizontally (unless 3<sup>rd</sup> party approved for vertical installation)
  - May be installed in a pit or a box
  - Be installed to facilitate repairs and testing (12 inches of clearance around assembly)











### IMPROPER INSTALLATIONS



### PRESSURE VACUUM BREAKER BACKFLOW ASSEMBLY

MAINTAINING AS AN ASSEMBLY



**CANOPY** 

ISOLATION VALVES (2)

TEST PORTS (2)


## PRESSURE VACUUM BREAKER (PVB) SPILL RESISTENT VACUUM BREAKER (SVB)

- Approved For:
  - Approved for Backsiphonage
  - Approved Health and Non Health hazard
- Common Applications
  - Landscape sprinkling systems
  - Janitorial chemical dispenser
  - Food service
  - Wash down hoses

## PRESSURE VACUUM BREAKER (PVB) SPILL RESISTENT VACUUM BREAKER (SVB)


- Installation Criteria
  - MUST BE INSTALLED VERTICALLY
  - INSTALLED 12 INCHES ABOVE ALL DOWN STREAM PIPING AND WATER USE
  - SHALL NOT BE IN A PIT OR BELOW GRADE
  - SHALL NOT BE SUBJECTED TO BACKPRESSURE


### PRESSURE VACUUM BREAKER (PVB)



# PRESSURE VACU 12 "

### IMPROPER INSTALLATIONS









### **PVB**

### **SVB**







### **BACKFLOW ASSEMBLY TESTING**

All backflow prevention assemblies must be tested annually by a Utah certified Backflow Assembly Tester

### **BACKFLOW ASSEMBLY TESTING**

**Using 10<sup>th</sup> Edition USC Testing Procedures** 

- TEST VALUE REQUIREMENTS
  - Reduced Pressure Zone (RPZ)
    - #1 Check 5.0 psid or above
    - #2 Check Recorded as Closed Tight or Leaked
    - Relief Port Opening point 2.0 psid or above
  - Double Check Valve (DC)
    - #1 Check 1.0 psi or above
    - #2 Check 1.0 psi or above

### **BACKFLOW ASSEMBLY TESTING**

**Using 10<sup>th</sup> Edition USC Testing Procedures** 

- TEST VALUE REQUIREMENTS
  - Pressure Vacuum Breaker (PVB)
    - Air Poppit Opens at 1.0 psi or above
    - Check Valve 1.0 psi or above
  - Spill Proof Vacuum Breaker (SVB)
    - Check Valve closes 1.0 psi or above
    - Air Poppit Opens 1.0 psi or above

### **BACKFLOW DEVICES**

### **BACKFLOW DEVICES**

Self Contained

Non-testable (Visual Inspection only)

Generally Not In line repairable

NO Isolation valves and test ports

### **BACKFLOW DEVICE TYPES**

Atmospheric Vacuum Breakers

Hose Bib Vacuum Breakers

Dual Check Valves

 Dual Check Valve with Atmospheric Vent

## ATMOSPHERIC VACUUM BREAKER (AVB)


- Approved Use
  - Health and Non- Health
  - Backsiphonage ONLY



## ATMOSPHERIC VACUUM BREAKER (AVB)

- Installation Criteria
  - Vertical Position ONLY (Air inlet up)
  - NO MORE than 12 hours continuous pressure in a 24 hour period
  - 6 inches above any downstream piping and water usage
  - Not subjected to backpressure
  - NO downstream valves
  - No pits

# ATMOSPHERIC VACUUM BREAKER (AVB)









#### **HOSE BIB VACUUM BREAKER**

- Approved Uses
  - Health and Non-health Hazards
  - Back siphonage
  - Low head backpressure
  - Threaded hose Connections ONLY
  - Non-Removable
- Maintenance
  - Drain for winter
  - Remove hoses when not in use














#### **DUAL CHECK VALVE**


- Approved uses
  - Approved for residential meter pit installations
     ONLY
  - Non-health
  - Water purveyor typically installs and maintains as secondary protection
  - Recommended 10 percent be tested or replaced each year by the water purveyor

# **Dual Check Valves**










#### THERMAL EXPANSION

- Must address thermal expansion!
  - MUST notify the customer of the dangers of thermal expansion
  - Thermal Expansion Tanks are installed by customer

# THERMAL EXPANSION TANK



# THERMAL EXPANSION TANK




#### **AIR GAP**

Air gap means a physical separation between the discharge end of a drinking water supply pipe and a receiving vessel

#### **AIR GAPS**

- Ultimate backflow protection
- Approved for Health and non-health
- High health hazard air gaps shall be inspected annually
- Physical Separation
  - 2 X pipe diameter
  - 1 inch minimum
  - Next to an obstruction
    - 3 X pipe diameter or
    - 1.5 inch minimum


### **AIR GAPS**



# **AIR GAP**



# OF BACKFLOW PREVENTION TO USE



	INDIRECT CROSS CONNECTION BACKSIPHONAGE ONLY		DIRECT CROSS CONNECTION BACKSIPHONAGE AND	
H E A L T H A Z A R D	PVB/SVB  RP  AIR GAP	NON- CONTINUOUS USE  AVB  AVB  PVB/SVB  RP  AIR GAP	RP AIR GAP	
NON NHEALTH	PBV/SVB  RP  DC  AIR GAP	AVB PVB/SVB DC RP AIR GAP	DC RP AIR GAP	